

## Mi Gamepad manual

Mi Gamepad must be connected to a TV, set-top boxes and other devices via Bluetooth for the first time only. In its further use as soon as you turn it on, it immediately will be automatically connected.

### Connecting to devices

When gamepad is off, press and hold the button Mi until it begins to flash quickly, enter the Bluetooth mode. The TV system / Mi Box consoles have set up the device to Connect - Bluetooth - Search for a device to search the list to locate and select the Mi joystick connection. After a successful pairing, gamepad vibrates and Mi button will light continuously.

### Switching on

Click on Mi button, after the successful activation of joystick, it automatically connects via Bluetooth to the nearest unit (in a device must also be enabled Bluetooth). After a successful pairing, gamepad vibrates and Mi button will lights continuously.


### Switching off

Press and hold Mi button until it turns off.

### Returning to main menu

Press Mi button when the gamepad is on.

## Overview



### Low battery notification

When Mi button flashes with an interval of 2 seconds, it indicates low battery. Please replace the batteries for normal operation of the joystick.

## Warranty

Warranty service is carried out in accordance with the law on «consumer rights» and the «Law on the quality of products.» The warranty service includes:

During the warranty period, you have the right to repair, exchange or return an item. For repair, replacement or return of goods you need a warranty card.

1. Within 7 days from the date of purchase, in case

of a problem of «fault list» Xiaomi service center determines the cause of the problem, then you can choose a free replacement of product, return or repair.

2. Within 8-15 days of purchase, in case of a problem of «fault list» Xiaomi service center defines the problem, then you choose a free replacement or repair of the goods.

3. Within 12 months from the date of purchase, in case of a problem from the «List of faults», Xiaomi service center defines the problem, then you are given a free repair.

The list of circumstances (including, but not limited to), in which the compensation is not possible:

- Repair of the device by unauthorized service centers, drop, neglect, abuse, liquid ingress, an accident, or if you have broken or slipped label and labeling devices;
- The warranty period is ended;
- Damage caused by force majeure;
- Problems that are not included in the list of faults;
- Damage to the device arising from use of the device investigation for other purposes or intentional damage.